



YARDART

995 Governor Dr. #103
El Dorado Hills, CA 95762

866 382-8600
info@yardart.com

GFRCFRT-1106 Large Sphere Fountain (2 pieces)

COMPONENTS AND PARTS LIST



Fountain holds
approximately 10
gallons of water

Water Feature
32"W x 33.5"H
93 lbs

Base
31.5"L x 31.5"W x 9"H
112 lbs

Pump Kit Parts List

PK300 pump (1)
Wedges (4)
Hose clamp (1)

* Tubing has been preassembled

This fountain is compatible with a
#10 or #7 Refill Device

Tools you will need

Level



This fountain takes cover
FTNCOV-MD

GFRFCFT-1106 Large Sphere Fountain (2 pieces)

ASSEMBLY INSTRUCTIONS

1. Make sure you are assembling your fountain on a level surface.
2. Unpack the provided pump.
 - a. **NOTE: Be sure to use the appropriate size adapter provided with the pump.**
3. Place the pump in the center of the basin.
 - a. Note – Keep 18” of the pump cord in the basin with the pump for easier installation. The remainder of the cord will drape over the back center of the basin.
4. Place the base over the basin with the access door at the back of the fountain. The basin should touch the inside wall of the base, which will allow enough space to access to the pump.
5. Run the pump cord through the channel that is cut into the bottom of the base.
6. Protect the top of the base with a towel, piece of cardboard, or something similar that will not scratch the surface of the base.
7. Rest the sphere on the base.
8. Hook the pump to the tubing that comes attached to the sphere.
 - a. Note - If necessary, use the hose clamp to secure the tubing to the pump.
9. Set the sphere into place on the base.
 - a. Note – Do not allow pump to run dry, as it will cause damage to the pump.

WINTER CARE AND GENERAL FOUNTAIN INSTRUCTIONS

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze.
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

For more Campania product information visit www.campaniainternational.com